

DOORKIT

INSTALLATION/SOFTWARE/USAGE

Q: Question

How can I change the device language while the device is locked?

A: Answer

Please follow the steps below.

Push and hold one of the buttons for 20 seconds. The screen may turn off which is normal.



Then a new prompt window will appear. Select “YES”.



Using the buttons to cycle through letters, type “ADMIN” as the password and then click enter.



Select “Return” icon and then navigate to “LANGUAGE” to change the language.

