



PLS

INSTALLATION/SOFTWARE/USAGE

Q: Question


How do I export data out of PLS?

A: Answer

Open PLS and click on the Bluetooth icon in the bottom right.



Under 'Database Management', click 'Export Data'



Insert the appropriate number of VINS, number of days, or data range, then press OK. Your data will be saved as a CSV file.



PL **ExportWindow** ×

- Number of VINS to export :
- Number of days to export :
- Date range to export :
Start: 24/05/2022 End: 24/05/2022