



SpeedPod

INSTALLATION/SOFTWARE/USAGE

Q: Question

How do I pair a SpeedPod to Windows with Bluetooth?

A: Answer

Preface: This pairing is only necessary the first time a new or updated device is connected to a computer. If your computer doesn't support Bluetooth, we offer an alternative solution called a "Bluetooth Dongle", which is a USB that will manually allow your computer to connect to SpeedPod via Bluetooth. For more information, please contact support at EZMetrology.

Before attempting to connect your SpeedPod device, you should be aware of your device's serial number to connect the proper device. The serial number is located on the back of the device, underneath the silicon cover.

For example:




For first time users:


In order to connect the SpeedPod to the MyPod program, you first pair the SpeedPod, via Windows, to the actual computer being used. By opening Bluetooth in the settings of your computer, you can pair it the SpeedPod by clicking 'Add Device':

Commented [TE1]: I would specifically mention "First Time connection" including the pairing procedure. and 'Already paired" with just clicking the icon
Also refer to the our Bluetooth dongle if the computer has no build in bluetooth..


Otherwise perfect!



Make sure that the SpeedPod is turned on and select the SpeedPod you would like to connect to.



Click 'Connect' button and the device should say 'paired' when the connection is successful. If a Connect button is not immediately visible then try scrolling down in the list slightly.



Tip: If you have paired the SpeedPod to your computer before, the SpeedPod should automatically connect/pair. A device may not immediately connect if it has had its firmware flashed or its Bluetooth chip updated. If this is the case then select the device in the Bluetooth & Other devices menu under the Other Devices heading, then click the Remove button. Pair the device again with the top instructions.

