

PLS


INSTALLATION/SOFTWARE/USAGE

Q: Question

How to add a user or change the password in PLS?

A: Answer

The Users tab should appear as below for a standard setup.



Add a User Group. Rename User Group.

Add a User. Rename User.

Click on "..." to change password of User.

Click OK.