



PLS

INSTALLATION/SOFTWARE/USAGE

Q: Question:

How do I install PLS?

A: Answer:

Please follow the steps below to install the PLS Software.


1. PLS Software Installation

1.1. Using Download Center on the application Computer


PLS can best be installed through Download Center. This application will not only manage your installation but also set restore points and allow to communicate directly with our support center.

Link: <http://ezmetrology.com/intdocs/SoftwareUpdates/DownloadCenter/Beta/DownloadCenter-2.2.1.0.exe>

After having installed the Download Center, the icon will be located on your desktop. Please run the software in “Administrator Mode” and navigate to PLS page by selecting the device you have, then by selecting the PLS icon.




Download Center Main Page



Download Center PLS Page

Select “Release PLS 5.1.0.0” from the drop-down menu on the left and click on “Install” button located in the left bottom of the screen. Follow the all-prompt windows to finalize the installation.



Download Center Install PLS



Depending on the network firewall or anti-virus on the system, it is possible that you may not reach to installers via Download Center. In that case you can follow any of the following cases.

1.2. Using Download Center on another Computer

In case the application computer is not connected to the internet, or firewall prevents downloading, any other computer can be used to follow the procedure described in 1.1.

Following a successful download, the installation files can from that computer be export to a flash drive and the programs can be transferred to the application computer.

Even in this scenario it is recommended to use the download center software on the application computer to install the software so that during usage you may use this application to communicate restore points to our support staff for questions or trouble shooting.

1.3. Using Direct Download (not recommended)

If for any reason the Download Center does not work, please follow the below steps.

IMPORTANT NOTE: The links below are version specific, verify with our support staff if there are any newer versions available.

PLS latest release version 5.1.0.0

LINK:

<https://www.ezmetrology.com/intdocs/SoftwareUpdates/PLS/PLS-5.1.0.0.exe>

PLS latest Beta version 5.1.11.0

LINK:

<http://ezmetrology.com/intdocs/SoftwareUpdates/PLS/Beta/PLS-5.1.11.0.exe>

Q: Question


How should I request and install PLS software license?

A: Answer

The first step to license your software is to generate the **.c2v file**. This file is unique file created with the computer identification number. In order to get the **.c2v file**, the software must be run. Once started, the file can be generated by going into “**Setting Menu**” and “**Software Admin**”.




Settings Icon



Software Admin Window

Fill in the boxes with your information (Company/User/Email) and then you can create .csv file After clicking **“Save Request”** button. Note that the location you saved this file and then send this file to license@ezmetrology.com




PLS License Window



License team will contact you and help for your license renewal. The team will send you “.v2c” file in an e-mail. Save this file onto your computer. Then, run your software and navigate to “**Settings Menu**” and select “**Software Admin**”. On this page select “**Import license**” and select the “.v2c” folder which is sent to you by EZMetrology. After importing the file restart the software and now your software is updated with new license.

Depending on the modules purchased, EZMetrology will include the modules in the license file. When licensed, software should be restarted.

The license has an “Expiration Date”. Please send us the license request file each year before its expiration date so EZMetrology can update your license file. No purchase is required for the yearly license file renewals.



Licensed Software Screen