



EZSpeed

INSTALLATION/SOFTWARE/USAGE

Q: Question

How to use the EZSpeed “in-line” with PLS 5.5 ?

A: Answer

1. Vehicle arrives down the line
2. Scan VIN by pressing the top button on the handle of the tablet (inside door, on travel sheet, under windshield)
3. Turn off ignition (to ensure vents are closed)
4. Roll all windows up and fully close all doors
5. Mount the magnetic target near the opening edge on the door to be measured (pictures)
6. Mount the EZSpeed to the vehicle behind the door to be measured (pictures)
7. Make sure the door being measured is displayed on both the gauge and tablet
8. Press START on the gauge to begin session
9. Open door to be measured (by default, first door is always left-front)
10. Wait for the six LEDs to turn off then close the door
11. If the door is completely latched, press the CLOSED button
12. If the door does not completely close, just open the door and measure again
13. Repeat steps 9-12 until the highest not closed and the lowest closed measurements are within 100 mm/s of each other (either a green or red LED will illuminate to indicate if the center value is within or if it exceeds tolerance)
14. If the evaluation appears red and the recorded value is above spec, immediately call a fitter to repair the door
15. Press END to return to the home screen
16. Dismount the gauge by lightly pressing up on the black suction cup under the gauge
17. Dismount the target
18. Repeat steps 5-16 for all other doors (make sure that all other doors are closed while measuring in a fitter is performing a repair)
19. Press “Vehicle Complete” on the tablet once all applicable doors have been inspected and measured
20. Repeat steps 2-19 for the next vehicle

Connecting an EZSpeed

- Can be done in the Startup or Settings window
- Search for devices until the device you are trying to connect to appears on the list
- Serial number is located on the bottom of the gauge
- Gauge must be turned on and at the home screen (with the vehicle icon that says SETUP and START) to pair
- Double-tap the gauge when it appears on the list to connect
- Tap “OK” to continue