

# SealScan


## INSTALLATION/SOFTWARE/USAGE

### Q: Question

What are layers and how can they be used?

### A: Answer

SealScan uses QCAD software to print and display the measurements taken by the device. By default, the Layer List is docked on the right side of the screen, just below the EZSealScanner plugin. New QCAD documents always contain a default layer with the name 0. This is the layer SealScan uses to display the device lines and animations.



Layer List options are as follows:



- Show All Layers - sets all layers to visible
- Hide All Layers - sets all layers to hidden
- Add Layer - add a new layer to the list
- Delete Layer - delete selected layer
- Edit Layer - edit data of selected layer

Additionally, next to each layer in the list, there are the following options:



- Toggle Layer Visibility – click to hide or display specific layer
- Toggle Layer Lock - click to lock or unlock specific layer.