



EZSLAM

INSTALLATION/**SOFTWARE**/USAGE

Q: Question

What to do if EZSlam2 does not show Pressure?

A: Answer

- Close the EZSlam software.
- Open the Notepad App.
- Create a new, empty document.
- Save it as flippressure.txt into the EZSlam-Data Folder:
C:\Users\Public\Documents\EZMetrology\EZSlam\Data
- Restart the EZslam software.
- Process all sessions.

If the Pressure still doesn't show, please contact the manufacturer on support@ezmetrology.com.