



SpeedPod

INSTALLATION/SOFTWARE/USAGE

Q: Question

How do I attach SpeedPod and where should it be positioned?

A: Answer

Attachment: To attach a SpeedPod rotate the grey lever to the perpendicular position, orientate the device so the interface is facing you and the suction cup is facing the door. Grasp the SpeedPod and place your thumbs on the thumb rests. Place the suction cup on the window; while using the thumb rests (Image 1-2), push the SpeedPod into the door and rotate the lever into the closed position. (Image 2-3)



Commented [TE1]: I would add a sketch / picture of the device with the 'thumb rests' clearly highlighted. Even maybe a sideview with arrows indicating the push force on both rests when flipping the handle

As far as where to place it we have/should take some pictures of the real locations on their doors. We can do that if we go back top MAP one of these days



Positioning for Window Measurement: Position SpeedPod near the top edge of window on the doors latch side. (Image 4 & 6)

Positioning for Speed Measurement: Position SpeedPod anywhere along the far edge of the door. (Image 4 & 5)



☒ Speed Measurement

☐ Window Vibration



Speed Placement



Window Vibration Placement