



Audit

INSTALLATION/SOFTWARE/USAGE

Q: Question

How should I request and install an Audit software license ?

A: Answer

The first step to license your software is to generate the **.c2v file**. This file is a unique file created with the computer identification number. To generate this file, launch Audit software; once started, navigate to the **Setting Menu** and **Software Admin**.

Then click on **“Request Changes”** . Fill in the boxes with your information (Company/User/Email) and click the **“Save Request”** button to generate a .c2v file. Save this file in a convenient location, then send it via e-mail to support@ezmetrology.com . Our support team will reply to you with a corresponding **“.v2c”** file. Save this file onto your computer, then relaunch Audit and navigate back to the **“Admin”** tab. On this window, select **“Import License”** and select the **“.v2c”** file that was sent to you. After importing the file, restart the software. The software should now be updated with the new license.

