



EZ3D

INSTALLATION/SOFTWARE/USAGE

Q: Question

How do I get a restore point after an unusual crash where the points seem to be lost?

A: Answer

This can be done manually through the 'backupXml' folder in the session folder:

"C:\Users\Public\Documents\EZMetrology\EZ3D\Sessions\Session 01\BackupXml"

in which "Session 01" is the name of the session one has an issue with. This folder contains backup copies from the main data file in the folder:

"C:\Users\Public\Documents\EZMetrology\EZ3D\Sessions\Session 01\Session 01.xml"

- 1) Close the software before continuing to make sure you are not using the file actively.
- 2) Rename the main data file "Session 01.xml" to, for example, "Session 01.xml _ missing data"
- 3) Copy one of the backup files in this location and rename it to "session 01.xml".
- 4) We suggest to aim for the biggest file in the backup folder. These files can actually be read in notepad to view available data.